

REMINGTON®

Guía de utilización y cuidados



- A. Rejillas con recubrimiento de cerámica, turmalina y titanio
- B. Ráfaga de aire frío
- C. Motor HTDC
- D. 3 ajustes de temperatura/2 de velocidad
- E. Gancho para colgar
- F. Concentrador
- G. Difusor

INSTRUCCIONES IMPORTANTES PARA EL CUIDADO

Cuando se usan electrodomésticos, en especial cuando hay niños presentes, se deben tomar en cuenta precauciones básicas, incluyendo las siguientes:

LEA TODAS LAS INSTRUCCIONES ANTES DE USAR.

MANTENGA ALEJADO DEL AGUA.

PELIGRO

Para reducir el riesgo de descarga eléctrica:

- Siempre desenchufar este artefacto de la toma de electricidad inmediatamente después de ser usado.
- No usar durante el baño o dentro de la ducha.
- No colocar o almacenar este aparato donde se pueda caer en una bañera o lavamanos.
- No colocar o dejar caer dentro del agua u otro líquido.
- No tomar un artefacto que haya caído dentro del agua. Desenchúfelo inmediatamente.
- Desenchufe este aparato antes de limpiarlo.

ADVERTENCIA

Para reducir el riesgo de quemaduras, fuego, descargas eléctricas o daños a personas:

- Este artefacto no está diseñado para ser usado por personas con incapacidad sensorial o mental (incluido niños) o que no tengan experiencia, a menos que se les supervise o capacite sobre el uso del producto por una persona responsable de su seguridad.
- Niños deben ser supervisados para asegurar que no jueguen con el artefacto.
- Use este artefacto sólo bajo el propósito del cual se describe en este manual. No utilice accesorios no recomendados por el fabricante.
- Nunca opere este aparato si:
 - El cable o el enchufe está dañado.
 - Se ha caído
 - Le ha ingresado agua
 - Se ha estropeado, roto o no funciona correctamente
 - En cualquiera de estos casos lleve inmediatamente el aparato al centro de reparaciones.
- **Nota:** Si el cable de alimentación está dañado este debe ser reemplazado por personal o un servicio técnico autorizado en Latino América.
- Mantenga el cable de electricidad fuera de superficies calientes.
- No enrolle el cable alrededor del aparato.

- Nunca lo use cuando duerma.
- Nunca tire o inserte ningún objeto dentro de las aberturas del aparato.
- No operar donde se usan aerosoles o se administra oxígeno.
- No conectar a una extensión eléctrica.
- No dirija el aire caliente a los ojos u otras áreas sensibles al calor.
- Sólo para uso doméstico.
- Accesorios pueden calentarse mientras se usan. Se deben enfriar antes de usar.
- Siempre almacene este electrodoméstico en un área libre de humedad. No lo almacene en temperaturas superiores a 60°C.



CUIDADO: No usar este aparato cerca de bañaderas, duchas ó otros recipientes con agua.

¿Cómo usar?

Técnicas básicas de secado rápido

- Suavemente remueva con una toalla el exceso de agua. Evite frotar el cabello con la toalla - esto causa daño al cabello y da frizz. Desenrede el cabello con un peine de pines anchos.
- Asegúrese que el secador este apagado. Enchufe el secador al tomacorriente.
- Coloque el secador en temperatura alta. Remueva el resto de la humedad del cabello secando el cabello rápidamente utilizando los dedos como peines.
- Cuando el cabello esta casi seco, rebaje la temperatura y la velocidad y empiece a peinarse.

- No enchufe o desenchufe este artefacto con las manos mojadas.
- Para protección adicional, se debe incorporar en la instalación eléctrica (disyuntor) con una corriente de corte residual que no exceda los 30mA. Para mayor información consulte a un instalador especializado (Argentina/Chile).

extendido y recto. Secar lentamente el cabello con el concentrador a lo largo de todo el cabello. Repita varias veces hasta que el cabello este completamente seco.

Para el cabello rizado:

Con la secador apagado, coloque el difusor en el extremo de la boquilla. Use el secador a baja temperatura y ajuste la velocidad y muévelo rápidamente sobre su cabeza. Mientras se seca el cabello, frótelo con su producto de peinado favorito o enrolle mechones de cabello alrededor de sus dedos para agregar definición. Cuando termine de secarse, asegure el estilo con la ráfaga de aire frío.

Cuidado del cabello

- Mantenga el secador a 8 pulgadas de distancia de su cabeza para evitar que su cuero cabelludo o su cabello se dañe.
- Siempre mantenga el flujo de aire del secador hacia abajo para cerrar la cutícula y dejar el cabello más brillante y sedoso.
- Para prevenir daño del calor y adicionar brillo al cabello, utilice un spray de protección antes de secarse el cabello.
- Para crear estilos de peinado con mucho volumen utilizar mousse en el cabello húmedo, distribuir el mousse por toda la cabeza desde el cuero cabelludo a las puntas y después secar el cabello normalmente.

Ráfaga de aire frío:

La ráfaga de aire frío fija el estilo deseado mediante una corriente de aire frío. Mantenga presionado el botón de ráfaga fría para fijar el estilo. Libere el botón para regresar al flujo de aire caliente.

Para cabello suave y liso

Con un cepillo grande y redondo o con un cepillo plano cepille el cabello desde abajo hasta que este completamente extendido y recto. Secar lentamente el cabello con el concentrador a lo largo de todo el cabello. Repita varias veces hasta que el cabello este completamente seco.

Limpeza y mantenimiento

Instrucciones de mantenimiento

- Mantenga todas las entradas de aire libre de acumulación de polvo. Ver “instrucciones de limpieza” abajo. No hay necesidad de otro mantenimiento ni de lubricación.
- Si el cable se tuerce o enreda debido al uso, periódicamente estréchelo. No enrolle el cable alrededor del artefacto.
- No repare el artefacto adquiera ayuda técnica.

Instrucciones de Limpieza

- Este secador necesita de mantenimiento mínimo para asegurar su vida útil.

- Mantenga la rejilla de ventilación libre de polvo, porque rejillas sucias y tapadas interfieren con la eficiencia del secador.

- Para limpiar las rejillas asegúrese que el sacador esté apagado y desconectado. Utilice un paño húmedo para limpiar.

Almacenamiento

Cuando el artefacto no está en uso desconecte la unidad, espere hasta que el artefacto se enfríe antes de almacenarlo. Mantenga el artefacto fuera del alcance de niños, y en un lugar seco. Nunca enrolle el cable alrededor del artefacto, el cable se puede gastar y romper prematuramente. Maneje el cable con cuidado sin jalarlo ni doblarlo ni torcerlo, especialmente cerca al enchufe.

Garantía - Ver folleto separado

© 2018 Spectrum Brands, Inc.

® Marca registrada y TM marca comercial por Spectrum Brands, Inc.

03/18 Job#19013-00

T22-7000203-A

Diseñado en USA

HECHO EN CHINA

D7777

Características eléctricas

110V: 127V~ 60Hz 1600W

220V: 220-240V~ 50/60Hz ; 220-240V~ 50-60Hz

REMINGTON®

Use and Care Guide



D7777

- A. Tourmaline, titanium and ceramic front grill
- B. Cool Shot button
- C. HTDC motor
- D. 3 heat/2 speed switch settings
- E. Hang loop
- F. 7mm Concentrator
- G. Diffuser

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be observed, including the following:

READ ALL INSTRUCTIONS BEFORE USING.

KEEP AWAY FROM WATER.

DANGER

To reduce the risk of electric shock:

- Always unplug this appliance from the electrical outlet immediately after using.
- Do not use while bathing or in the shower.
- Do not place or store this appliance where it can fall or be pulled into a tub or sink.
- Do not place or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Unplug this appliance before cleaning it.

WARNING

To reduce the risk of burns, fire, electric shock or injury to persons:

- An appliance should never be left unattended when it is plugged in.
- This appliance is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water.

NOTE: If the power supply cord is damaged, it should be replaced by qualified personnel or in Latin America by an authorized service center.

- Keep the cord away from the heated surfaces. **Do not wrap the cord around the appliance.**
- Never use while sleeping.
- Never drop or insert any object into any of the appliance's openings.

- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair and the like.

- Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.

- Do not use an extension cord.

- Do not direct hot air toward eyes or other heat-sensitive areas.

- Do not place appliance on any surface while it is operating.

- Always store this appliance and cord in a moisture-free area. Do not store it in temperatures exceeding 60°C (140°F).



CAUTION: This product is not suitable for use in bath or shower.

SAVE THESE INSTRUCTIONS

How to Use

Basic Drying Techniques

- Gently towel dry hair to remove excess water. Avoid rubbing hair with towel – this creates split ends and frizziness. Detangle hair with a wide-toothed comb.
- Be sure dryer is turned off. Plug dryer into an electrical outlet.
- Turn the dryer on and set it to a high heat and speed. Remove some of the additional moisture from your hair by briskly blow drying it all over, using your fingers to “comb” through hair.
- When hair is almost dry, lower the heat and speed to the desired settings and begin to style.
- Divide hair into manageable sections. Begin at the nape of your neck and brush hair, following the movement of the brush with the dryer. Continue working your way up to your scalp, then to the sides and the front, drying small sections at a time.
- When finished, turn dryer off to “0” setting and unplug.

- This appliance is for household use only.

- Attachments may be hot during use. Allow them to cool before handling.

- Do not plug or unplug this appliance when your hands are wet.

- For additional protection the installation of a residual current device (RDC) with a rated residual operating current not exceeding 30mA is advisable. Ask an electrician for advice (Argentina/Chile).

For straight, smooth hair:

Brush hair from underneath using a large, round brush or paddle brush. Pull hair down until the hair is fully extended and taut. Run the dryer slowly down the length of the hair several times until dry. Repeat with all sections of hair until it is completely dried.

For curly hair:

With the dryer turned off, attach the diffuser to the end of the nozzle. Use the dryer on a low heat and speed setting and move it quickly about your head. As you dry your hair, scrunch it with your favorite styling product or twirl strands of hair around your fingers to add definition. When finished

drying, lock in the style with the Cool Shot.

Cool Shot:

The Cool Shot sets the style by blowing a cool stream of air. Press and hold the cool shot button to set style. Release the button to return to warm air flow.

Using Attachments:

The attachments can get hot so use with the lower heat setting. To use the attachments, (concentrators, diffuser) push the one of your choice onto the front of the dryer until it fits securely into position. To remove, pull attachment loose.

Hair Care Tips

- Keep the dryer about 8 inches away from your head to avoid burning scalp or damaging hair.
- Always keep the dryer pointed down the hair shaft to smooth the cuticle and create a silky, shiny style.
- To help prevent heat damage and add shine, spritz damp hair with heat protection spray before blow drying.
- To create a style with lots of body, apply volumizing mousse to towel-dried hair. Distribute it evenly from roots to ends, then blow dry as usual. Hair will be soft, shiny and full of volume.
- For a super smooth, salon-like blow dry, finish by running a straightening iron over dried hair.
- For a quick touch-up between shampoos, mist hair to dampen it, then style with dryer.

Cleaning and Maintenance

Maintenance instructions

The dryer needs minimum maintenance to ensure the best performance and long life.

- Do not attempt to repair the appliance yourself.
- Keep all intake openings clear of dust accumulation. See “Cleaning Instructions” below. No other maintenance or lubrication is required.
- If the cord becomes twisted due to use, periodically straighten it. Store appliance and cord where they will not be damaged. Do not wrap cord around dryer.
- No user serviceable parts.

Cleaning instructions

The air filter should be cleaned regularly, since a dirty or clogged filter will impair the efficiency of the dryer.

1. To clean, make sure dryer is turned off and unplugged.

2. If the unit is dirty, wipe it with a damp cloth.

Storage

When not in use, unplug the unit. Allow it to cool, and store out of reach of children in a safe, dry location. Never wrap the cord around the appliance, as this will cause the cord to wear prematurely and break. Handle cord carefully, and avoid jerking, twisting, or straining it, especially at plug connections.

Performance Guarantee - See insert

© 2018 Spectrum Brands, Inc.
© Registered Trademark and TM Trademark of Spectrum Brands, Inc.
03/18 Job#19013-00

T22-7000203-A

Dist. by:
Spectrum Brands, Inc.,
Middleton, WI 53562

Designed in USA

MADE IN CHINA

D7777

Electrical Characteristics:

110V: 127V~ 60Hz 1600W

220V: 220-240V~ 50/60Hz ; 220-240V~ 50-60Hz