REMINGTON®

Para el manual digital, visite **www.Remingtonlatam.com**

Guía de Utilización y Cuidados

MB20A

Listado de piezas y partes

1. Cabezal con cuchilla de 30mm
2. Botón "ON/OFF"
3. Indicador de carga de LED
4. Cuchilla detalladora de 7mm
5. Peines (1.5, 3, 6, 9,12, y 15mm)
6. Peine ajustable

INSTRUCCIONES IMPORTANTES PARA EL CUIDADO

Cuando se usa un electrodoméstico, se deben tomar precauciones básicas incluyendo las siguientes. **Lea todas las instrucciones antes de usar este electrodoméstico.**

PELIGRO

Para reducir el riesgo de incendio o electrocución, siga cuidadosamente las siguientes instrucciones:

- No coloque o almacene este electrodoméstico en donde pueda caer o ser arrojado a la tina o al lavamanos cuando éste se encuentre enchufado.
- A menos que se encuentre recargando, siempre desenchufe este electrodoméstico del toma corriente inmediatamente después de cada uso.
- Desenchufe este electrodoméstico antes de limpiarlo.

CUIDADO

Para reducir el riesgo de quemaduras, fuego, electrocución o heridas a personas:

- Este artefacto no está diseñado para ser usado por niños, personas con incapacidad sensorial o mental, o que no tengan experiencia, a menos que se les supervise o capacite sobre el uso del producto por una persona responsable de su seguridad.
- Niños deben ser supervisados para asegurar que no jueguen con el artefacto.
- Nunca opere este aparato si:
  – El cable o el enchufe está dañado.
  – Se ha caído
  – Se ha estropeado, roto o no funciona correctamente
  – En cualquiera de estos casos lleve inmediatamente el aparato al centro de reparaciones.
- Nunca utilice el aparato si el cable de carga USB ha sido dañado o caído al agua.
- Mantenga el cable de electricidad fuera de superficies calientes.
- No enrolle el cable alrededor del aparato.
- Nunca lo use cuando duerma.
- Nunca tire o inserte ningún objeto dentro de las aberturas del aparato.
- No operar donde se usan aerosoles o se administra oxígeno.
- No conectar a una extensión eléctrica.
- Sólo para uso doméstico.
- No lo almacene en temperaturas superiores a 60°C.
- Desconecte el dispositivo del puerto USB inmediatamente después de la carga.
- Remueva el cable del aparato para almacenarlo.
- No enchufe o desenchufe este artefacto con las manos mojadas.
- No use un cable de extensión o un convertidor de voltaje para cargar este producto.
- Las afeitadoras, incluidas las recortadoras, son para uso exclusivo en la vello facial. No intente cortar cabello o el vello en alguna otra parte de su cuerpo.
- Cuando el aparato se utiliza en un baño, desenchúfelo después de usarlo, ya que la proximidad del agua representa un peligro incluso cuando el aparato está apagado.
- Para protección adicional, se debe incorporar en la instalación eléctrica un dispositivo de corriente residual (disyuntor) con una corriente de corte residual que no exceda los 30mA. Para mayor información consulte a un instalador especializado (Chile/Argentina).

CUIDADO: No usar este aparato cerca de bañaderas, duchas ó otros recipientes con agua.

GUARDE ESTAS INSTRUCCIONES

Carga del Aparato

Nota: se recomienda cargar completamente el aparato antes de utilizarlo por primera vez. Consulte los tiempos de carga indicados en este manual.

- Asegúrese de que el aparato está apagado.
- Si utiliza el cable USB para conectar el aparato, asegure de conectarse a una fuente con las siguientes características eléctricas: 5.0V⎓ 0.5A
- El tiempo de funcionamiento del aparato completamente cargado es de hasta 60 min.
- El tiempo de carga con el aparato descargado es de 4 horas.

Nota: para preservar la vida útil de la batería, deje que se agoten del todo cada 6 meses y luego recárguelas completamente.

Indicador de carga

Nivel de carga	Luces indicadoras de carga	
	Durante carga	Durante uso
Cargando	Las luces se desplazaran de abajo hacia arriba	-
Completamanete cargado	Todas la luces se mantendrán encendidas por 5 minutos y luego se apagarán	Las luces se moverán de forma constante de abajo hacia arriba y viceversa
Carga de bateria baja Menos de 3 minutos disponibles	-	La luz inferior titilará constantemente

Luces	Nivel de carga
Luz inferior titilando	Carga baja
Luz inferior encendida	33%
Luz inferior y luz media encendidas	33 - 66%
Todas encendidas	66 - 100%

- Desconecte el cargador cuando la unidad este completamente cargada.

Instrucciones de Uso

- Encienda el aparato presionando el interruptor de encendido/apagado.
- Antes de empezar a cortar, peine la barba o el bigote con un peine fino.
- Las cuchillas se pueden posicionar de forma frontal o reversa dependiendo el área donde se quiera llegar.

Cómo Quitar y Poner las Guías Cortadoras

- Seleccione el peine con la longitud de corte deseada. Coloque el peine por encima de la cuchilla y presione con suavidad hacia abajo hasta que haga clic al encajar.
- Para retirar el peine, agarre el peine y tire firmemente hacia arriba alejándolo del aparato.

Para Cortar la Barba

- Seleccione el peine con la longitud de corte deseada.
- Si está utilizando el aparato por primera vez, le recomendamos seleccionar la máxima longitud de corte.
- Encienda el aparato.
- Coloque la parte superior plana del peine fijo contra la piel.
- Deslícelo lentamente sobre la piel. Si es necesario repita la pasada en distintas direcciones.
- Si durante el proceso de corte se acumula mucho vello en el peine, apague el aparato, extraiga el peine guía y límpielo con un cepillo.

Para Conseguir un Afeitado Rápido

- Para conseguir un afeitado rápido al cortar la barba de varios días o de cualquier longitud, siga los pasos arriba indicados sin acoplar un peine a la cuchilla.
- Coloque la parte superior plana de la cuchilla contra la piel y deslice lentamente a contrapelo.

Nota: Cuando el vello tenga longitud considerable y se busque un afeitado, utilice el cortador en dirección vertical de abajo hacia arriba.

Recorte y Detallado

- Sostenga el aparato sin peines acoplados, con el lado trasero de la cuchilla hacia usted.
- Comience con las cuchillas ligeramente apoyadas sobre su piel, y realice movimientos hacia el borde de la barba para recortar las zonas deseadas de la cara.
- Dé la forma deseada.

Cuidado del Aparato

- Para asegurar el funcionamiento duradero del aparato, límpielo después de cada uso.

Cambio de la Batería

- La batería debe retirarse del aparato antes de desecharse.
- El aparato debe estar desconectado de la fuente de poder al retirar la batería.
- Asegúrese de que el aparato está totalmente descargado.
- Retire el peine guía.
- Desconecte la batería del circuito impreso y del armazón interno.
- La batería debe desecharse de forma segura.

CUIDADO: ESTAS BATERÍAS A BASE DE NÍQUEL Y CADMIO, NÍQUEL-HIDRURO METÁLICO O ION-LITIO DEBEN SER RECICLADAS O DESECHADAS CONFORME A LAS REGULACIONES ESTATALES O LOCALES QUE CORRESPONDAN.

No queme ni mutile las baterías porque podrían explotar o liberar materiales tóxicos. No provoque corto circuitos con las mismas ya que podrían producir quemaduras.

Garantía - ver folleto separado

© 2020 Spectrum Brands, Inc.

® Marca registrada y TM marca comercial de Spectrum Brands, Inc.

05/20 Job#27686-00 **T22-7001557-A**

HECHO EN CHINA

Características eléctricas
Modelo MB20A
100-240V~ 50/60Hz 0.1A Max

Esta garantía no será válida cuando sea contraria a las leyes de los Estados Unidos y otras leyes aplicables, o donde la garantía esté prohibida bajo cualquier sanción económica, leyes de control de exportaciones, embargos u otras medidas comerciales restrictivas impuestas por los Estados Unidos u otras jurisdicciones aplicables. Esto incluye, sin limitación, cualquier reclamo de garantía que implique a partes de, o de otra manera ubicadas en, Cuba, Irán, Corea del Norte, Siria y la disputada región de Crimea.

REMINGTON®

For digital manual,visit **www.Remingtonlatam.com**

Use and Care Guide

MB20A

List of pieces and parts

1. 30mm Blade
2. On/Off Switch
3. LED charging indicator
4. 7mm detail blade
5. Guide combs (1.5, 3, 6, 9,12, and 15mm)
6. Adjustable comb

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be observed, including the following. **Read all instructions before using this appliance.**

DANGER

To reduce the risk of fire or electric shock, carefully follow these instructions:

- Detach the appliance from the power supply cord before cleaning.
- Except when charging, always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

- An appliance should never be left unattended when it's plugged in, except when charging a rechargeable appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug or if it is not working properly, if it has been dropped or damaged.
- Never operate this appliance if the USB charging cable has been damaged.
- Keep the USB charging cable away from heated surfaces.
- Never drop or insert any object into any of the appliance's openings.
- Household use only.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Always attach the plug to the appliance, then to the outlet. To disconnect, turn all controls to OFF, then remove plug from outlet. Detach removable power cords from appliances for storage.
- Remove appliance from USB port immediately after charging.
- Do not plug or unplug this appliance when your hands are wet.
- Do not use an extension cord or a voltage converter with this appliance.
- Do not wrap the cord around the appliance.
- Always store this appliance and cord in a moisture-free area. Do not store it in temperatures exceeding 140°F (60°C).
- Do not use this appliance with a damaged or broken head or cutters, as facial injury may occur.
- The power unit is intended to be correctly oriented in a vertical or floor mount position.
- The product can not be used or charged through electrical outlet source, only use by USB mode.
- Shavers, including the trimmer, are for use on facial hair only. They should not be used for shaving the hair on your head or any other part of your body.

For additional protection the installation of a residual current device (RDC) with a rated residual operating current not exceeding 30mA is advisable. Ask an electrician for advice (Argentina/Chile).

CAUTION: This product is not suitable for use in bath or shower.

SAVE THESE INSTRUCTIONS

Charging

Note: It is recommended to fully charge your appliance before using for the first time. Please refer to the charge times shown in this book.

- Ensure the product is switched off.
- Connect the product to the USB cable and then connect the USB end of the cable to a powered USB port: 5.0V⎓ 0.5A
- Run time from fully charge is up to 60 minutes.
- Charge time from empty is 4 hours.

Note: To preserve the life of your batteries, let them run out every 6 months then fully charge.

FUEL GAUGE

Charge Level	Fuel Gauge Lights	
	During Charging	During Use
Charging	Lights will cycle in an upwards pattern	-
Fully Charged	All lights will remain lit for 5 minutes and then switch off	Lights will cycle in an upwards and downwards pattern
Battery charge is low (3 minutes or less run time available)	-	Bottom light will flash

Lights	Remaining Charge Level
Bottom light will flash	Battery charge low
Bottom light on	33%
Bottom and middle light on	33 - 66%
All lights on	66 - 100%

Instuctions for Use

- Switch the product on by pressing the On/Off switch.
- Always comb your beard or mustache with a fine comb before you start trimming.
- To fit, position the blade as desired then insert it into the opening and press it downwards until it clicks into place.
- The T-blade and micro detail blade can be positioned facing upwards or downwards to help you trim difficult to reach areas.

Attaching & Removing The Combs

- Select the desired trimming length comb. Place the comb over the top of the blade and gently push this down onto the blade until it clicks into place.
- To remove the comb, grasp the comb and pull firmly upwards and away from the grommer.

To Trim The Beard

- Select your desired trimming length comb. If you are trimming for the first time satart with the maximum trimming length setting.
- Turn the unit on.
- Place the flat top of the fixed comb against the skin.
- Slowly slide through the hair. Repeat from different directions as necessary.
- If hair builds up in the trimmer comb during the trimming process, switch the unit off, pull off the comb and brush the hair off.

To Get a Shaven Look

- To trim any length of beard or stubble hair for a clean, shaven look then follow the above steps without a comb attached to the blade head.
- Place the flat top of the blade against the skin and slowly slide through the hair against the direction of growth.

Note: When the hair has a considerable length and a shave is sought, use the cutter in a vertical direction from bottom to top.

Trimming & Edging

- To trim any length of beard or stubble hair for a clean, shaven look then follow the above steps without a comb attached to the blade head.
- Place the flat top of the blade against the skin and slowly slide through the hair against the direction of growth.

Cleaning & Care

- To ensure long lasting performance of the groomer, clean after each use.
- The easiest and most hygienic way to clean the groomer is by rinsing the head under the tap after use while the blades are running.

Battery Removal:

- The battery must be removed from the appliance before it is scrapped.
- The appliance must be disconnected from the supply mains when removing the battery.
- Ensure the trimmer is discharged of all power.
- Remove the comb attachment.
- Pry off the bottom gap below the grips.
- Press in exposed tabs and pull internal frame out.
- Disconnect the battery from the circuit board and internal frame.
- The battery is to be disposed of safely

CAUTION: THIS LITHIUM BATTERY MUST BE RECYCLED OR DISPOSED OF IN ACCORDANCE WITH STATE AND LOCAL REGULATIONS.

Do not burn or mutilate, as they may burst or release toxic materials. Do not short-circuit, as this may cause burns.

Warranty - see separate insert

© 2020 Spectrum Brands, Inc.

® Registered Trademark and
TM Trademark of Spectrum Brands, Inc.

05/20 Job#27686-00
T22-7001557-A

DESIGNED IN USA
MADE IN CHINA

Electrical Characteristics
Model MB20A
100-240V~ 50/60Hz 0.1A Max

This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under any economic sanctions, export control laws, embargoes, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the disputed Crimea region.